

# Corner & Peninsula Column Modules

## Specifications:


Corner and Peninsula Column Modules allow multiple configurations of Island and Wall Structural Modules to form a variety of assemblies. In addition they may be used as a plumbing or electrical drop.

The Column Modules are available in heights to match the Structural Modules. Each module is furnished with

removable access panels and attachment hardware.

**Module Ledge must be ordered separately.**

### 3" Deep Wall Inside Corner Column




#### Inside Corner Column

Height	Part Number
36"	<b>F41M3603-00</b>
38"	<b>F41M3803-00</b>
46"	<b>F41M4603-00</b>
48"	<b>F41M4803-00</b>


#### Peninsula Column

Height	Part Number
36"	<b>F42M3603-00</b>
38"	<b>F42M3803-00</b>
46"	<b>F42M4603-00</b>
48"	<b>F42M4803-00</b>

### 3" Deep Wall Peninsula Corner Column



### 9" Deep Wall Inside Corner Column




#### Inside Corner Column

Height	Part Number
36"	<b>F41M3609-00</b>
38"	<b>F41M3809-00</b>
46"	<b>F41M4609-00</b>
48"	<b>F41M4809-00</b>

#### Peninsula Column

Height	Part Number
36"	<b>F42M3609-00</b>
38"	<b>F42M3809-00</b>
46"	<b>F42M4609-00</b>
48"	<b>F42M4809-00</b>

### 9" Deep Wall Peninsula Corner Column



# Corner & Peninsula Column Modules

**Specifications:**


Corner and Peninsula Column Modules allow multiple configurations of Island and Wall Structural Modules to form a variety of assemblies. In addition they may be used as a plumbing or electrical drop.

The Column Modules are available in heights to match the Structural Modules. Each module is furnished with


removable access panels and attachment hardware.

**Module Ledge must be ordered separately.**

**12" Island Corner Column**



Height	Part Number
36"	<b>F40M3612-00</b>
38"	<b>F40M3812-00</b>
46"	<b>F40M4612-00</b>
48"	<b>F40M4812-00</b>



**Possible Alpha System Assembly configurations using Island Corner Column Modules**